


TOW FLAP HEAT SHIELD INSTRUCTIONS



2011-ON FORD F-250, F-350 2002-08 DODGE/RAM 1500 & 2003-09 DODGE/RAM 2500, 3500

Read and follow these instructions along with the standard instructions carefully before installing or using this mud flap.

NOTICE TO INSTALLER: Even if familiar with product, read instructions prior to installation as improvements may be made without notice. Always handle components with care. When done, these instructions must be given to the consumer.

NOTICE TO CONSUMER: Before using this product, read instructions. Save these instructions for future reference.

PREPARATION

TOOLS NEEDED

- Ratchet with 9/16" socket
- 9/16" Wrench
- Protective eyewear

▲ CAUTION: To avoid galling of stainless steel hardware, use anti-galling spray, grease or lubricant on threads and avoid high speed when fastening. Do not use impact tools for stainless steel hardware.

▲ CAUTION: Over tightening hardware may damage components or truck.

▲ CAUTION: After installation, do not touch heat shield, hot exhaust results in high temperatures on heat shield.

▲ WARNING: Ensure exhaust fumes are NOT directed or redirected toward any plastic or flaps, including on the vehicle. Additional precautionary measures may need to be taken to divert exhaust.

1: INSTALLING HEAT SHIELD

A. Heat shield mounts to exhaust side of tow flap. With tow flap installed on truck, place flat washers on bolts then insert bolts through existing holes in tow flap with threads facing exhaust. Place (1) washer and (2) nuts on each bolt and tighten.

B. Position heat shield against tow flap while aligning holes in shield with exposed bolt threads. Secure using lock washers and nuts, then tighten.

